

EN User's Manual

# OUTDOOR DECORATIVE LED LIGHT WITH LADY SHAPE



## Technical features



LED LAMP SERIES

## 1. INTRODUCTION

Read this guide carefully before use and keep it handy for future references, use the lamp in conformity with the utilization precautions. The manufacturer declines all responsibility for incorrect or improper use of the product or power supply or for any use not specified in this manual.

## 2. PRECAUTIONS

### LIGHT

1. Do not expose lamp to fire or high temperature.
2. Do not attempt to dismount lamp assembly to avoid risk of electrical shock or alteration of water-proofing; failure to comply will automatically void warranty.
3. Do not try to charge the lamp with chargers other than the one supplier in the package.
4. Although impact resistance, avoid submerging in water and bright sunshine over extended period.
5. To extend battery lifespan, kindly ensure first charge of 8 hours.
6. Product is not intended for children.

### CHARGER

1. Do not use it near a heat source or expose to fire.
2. Keep it out of reach to children.
3. Do not touch the charger while charging.
4. Do not try to open charger; faulty charger should be return to dealer.
5. Disconnect the charger after charging.
6. Do not use outdoors as charger is not water proof.

### 3. SPECIFICATION

1. Led lamp in PE material with building RGB SMD led; Waterproof IP66, for outdoor decoration for home, hotel, restaurant, party....
2. Battery type 18650 Lithium battery, rechargeable.
3. With remote control to manage the brightness, color selection (16 static colors) and 4 lighting modes (flash, strobo, fade and smooth).
4. Works up to 8 hours when setting 1 color, 4-6 hours when setting different modes; charging for 4/6 hours.
5. Ambient temperature: -10°C ~ 60°C.
6. Input voltage: 110V-240V; Output voltage: 4.2 V 800mA.
7. Wattage: 17.6W.
8. Product size: L48\*W38\*H206cm.

### 4. INSTRUCTIONS

1. **Remove** the **Charger Seal** to plug in DC for charging. To maximize battery lifespan, please conform to first usage precautions.
2. After charging, cover the DC input with the **Charger Seal** and ensure it is securely fastened to prevent water seepage.
3. To **Turn ON**, Press "ON/OFF" button, this will start at the last mode which was previously selected.
4. To **OFF** simply Press "ON/OFF" button.

DC INPUT


ON / OFF



## 5. FUNCTIONS

1. Power-ON in "red" and OFF in "black".
2. Brightness Control (in static mode).
3. Speed Control (in Flash, Strobe, Fade, Smooth mode).
4. Quick select of 16 static colors.
5. FLASH Mode: Flash 7 colors continuously.
6. Strobe Mode: Blinking from white.
7. Fade Mode: Blinking with 7 colors.
8. Smooth Mode: Flow of full color spectrum.
9. Battery-3V.
10. To activate, pull power separation film from battery unit (end of remote controller).

**Note: Remote is not waterproof and not interned for children**



## 6. REMARKS

1. For first use, please switch on the lamp using the on/off button on the bottom of the lamp for activate the functions.
2. For long time disuse, please recharge it first, and then press the green (G) button of remote 12 seconds for resetting the device to the factory settings. Or, recharge it once a month to prolong the service life of the product.



In compliance with EU Directive WEEE this product is marked with this symbol. It means that used electrical and electronic products should not be mixed with general household waste. There is a separate collections system for these products in compliance with WEEE directive, otherwise contaminative and hazardous substances can pollute the environment.

