

### **User Guide**

Direktronik Pro Managerad 8xPoE + 2xRJ45 2xSFP Uplink

### **Item Listing**

Carefully open the box, inside box should have the following items:

- PoF Switch \* 1
- User Manual \* 1
- Console Cable\*1

Mounting accessories(Rack Mount Kit \*2: Feet \*4: Screw \*8)

If damage or shortage of found objects, please contact local dealers.

### 1. Product Description


20117395 provides rich of two layer management function, has excellent of performance and friendly of management interface, can full meet user of need, including system configuration, and port configuration, and MAC bound, and MAC filter, and VLAN configuration, and SNMP configuration, and ACL configuration, and QOS configuration, and IP basic configuration, and AAA configuration, and MSTP configuration, and IGMP SNOOPING configuration, and GMRP configuration, and EAPS configuration, and RMON configuration, and cluster management, and ERPS configuration, and log management, and PoE configurations.

1-8 ports support PoE feature, support IEEE802.3af/802.3at standard, automatic detection and identification in accordance with standards of electrical equipment, and through the network cable for the power supply.

# 2. Appearance Description

### 1. The front panel

PoE Switch front panel:




### 2.2 LED Indicator Light

LED	Color	Description
PWR	Green	Death: Switch does not power on
		Permanent: the Switch is powered on
SYS	Green	Blinking: the system works
		Out: the system is starting or has no power
LNK/ACT	Green	Death: not connected to the network equipment
		Green light: connected to 10/100/1000Mbps devices
		Blinking: connected devices are data transmission
PoE	Orange	Death: port is not for terminal equipment power supply
		Permanent: electrical equipment connected with it, and the
		normal power supply

#### 2 3 Back Panel

Back panel: AC power connector, AC input range 100-240V, 50/60HZ, a grounding screw holes



#### AC power port

This is an AC power socket, connect the negative plug of the power cord to this interface, and connect the positive plug to the AC power supply.

#### Lightning protection grounding pole

It is located to the left of the power interface. Please use wire grounding to prevent lightning strike.



Precautions: The product comes with a built-in feature for a permanently connected protective grounding conductor. This conductor should be expertly installed into the building's grounding system by a qualified professional.



## 3. Installation of Equipment

#### **Announcements**

To prevent equipment damage and personal injury caused by improper use, please observe the following precautions:

Before cleaning Switch should Switch power supply plug pulled out. Do not use wet cloth to wipe the Switch, do not use liquid to clean the Switch;

Do not Switch on the water or wet places, and prevent water or moisture from entering the Switch chassis:

Do not place the Switch box in unstable or table, in case of fall, will cause serious damage to the Switch;

Should maintain good indoor ventilation and keep the ventilation holes of the Switch open;


Switch to the proper voltage to work properly, make sure the Switch working voltage matches the voltage indicated;

To avoid the danger of electric shock, do not open the chassis without authorization; If any fault occurs, contact professional maintenance personnel.

### 3.1 Desktop Installation


Placed the bottom of the Switch on large enough and stable desktop;

Tear off pad surface of the paste that comes with random paper, paste the pad to Switch the Groove at the bottom of the housing to prevent external vibrations; Resetting the Switch on the Workbench cautiously.



#### 3.2 Rack Installation

Check EIA-19inch machine Cabinet of grounding and stability, first, with screws will installation hanging ear fixed in Switch front Panel sides will Switch placed in machine Cabinet of a bracket, along machine Cabinet guide slot Mobile Switch to right location, then, with screws will installation hanging ear fixed in machine Cabinet ends of fixed guide slot, ensure Switch stable to installation in machine Cabinet slot bit of bracket. Equipment mounting brackets are not used for load-bearing, it only plays the regular role. When installing the equipment cabinet, box bottom bracket (fixed on the Cabinet) to support the device.



#### 3.3 Turn on Switch

Please connect the AC power cord into the rear of the Switch and to an electrical outlet (preferably one that is grounded). When the Switch is power on, the LED indicators flash momentarily for one second, which represents a resetting of the system. The Power LED indicator turns on green.

Note: Please confirm the voltage is correct before power on, otherwise the Switch will be damaged.

(The power input is: 100-240Vac, 50/60Hz.)



# Specifications

Direktronik Pro Managerad 8xPoE + 2xRJ45 2xSFP Uplink
IEEE 802.3, IEEE 802.3u, IEEE 802.3ab, IEEE 802.3z, IEEE 802.3x,
IEEE 802.1X, IEEE 802.1q, IEEE 802.1p, IEEE 802.1d, IEEE 802.1w,
IEEE 802.3ad, IEEE802.3af, IEEE802.3at
10BASE-T: UTP category 3,4,5 cable (≤100m)
100BASE-TX: UTP category 5, 5e cable (≤100m)
1000BASE-T: UTP category 5e, 5 cable (≤100m)
1000BASE-X: MMF, SMF
8K, Auto-learning, Auto-update
Store-and-Forward
10Base-T: 14881pps/port
100Base-TX: 148810pps/ port
1000Base-T : 1488095pps/ port
24Gbps
280*180*44mm
1pcs
100-240V AC, 50/60Hz
Port 1~8
Mode A 1/2 (+) , 3/6 (-)
Voltage: 54V Power: 30W(Max)
130W
150W
0°C ~ +40 °C
-40 °C ~ +70 °C
10% ~ +90% non-condensing
5% ~+ 90% non-condensing